



INSTRUCTION OF REPLACEMENT OF DIFFERENT OPTIC ACCESSORIES






Push the new one back to the











INSTRUCTION FOR THE MULIPLE CONNECTOIN


HEADS	CUT-OUT	
Two heads	$(90 \times 2-5) \times 85$ mm	
Three heads	$(90 \times 3-5) \times 85$ mm	
Four heads	$(90 \times 4-5) \times 85$ mm	
Five heads	$(90 \times 5-5) \times 85$ mm	
•••	•••	












Independent external driver, recessed mounted.









- Use only drivers that comply with IEC or CE safety standards.
- Check if the power supply match with the luminaire.
- Must consider the maximum current value displayed on the label of the luminaire.
- The voltage displayed on the luminaire is not used to select the constant voltage driver, but the voltage covered by the selected constant current driver.
- Take suitable ESD measures to avoid touching bare conductors.
- LED chips can be damaged if be in touch with chemical material or gas. Therefore, it is not allowed to clean the LED housing or luminaire by chemicals.
- The following items are confirmed to have negative impact on the performance of the luminaire, avoid to keep luminaire in the same circumstance with them.

Methyl acetate or ethyl acetate (i.e., nail polish remover)

Cyanoacrylates (i.e., "Superglue")

Glycol ethers (including Radio Shack ® Precision Electronics

Cleaner - dipropylene glycol monomethyl ether)

Formaldehyde or butadiene (including Ashland PLIOBOND ® adhesive)


Dymax 984-LVUF conformal coating

Loctite Sumo Glue Loctite 384 adhesive Loctite 7387 activator

Gorilla Glue Bleach, Bleach-containing cleaners, sprays

- Remove the insulation material from the luminaire or provide enough space so that the temperature raising will not overpass the limited TC.
- LED chip is very sensitive to switching transients, therefore, LED lamps and appliances must be connected after power cut off, no hotswappable.
- Recommends using the driver indicated on the luminaire manual.
- Must consider the polarity of the product.
- -If the external flexible cable or cord of this lamp is damaged, the cord should be replaced by the manufacturer or its service agent or a similarly qualified person
- -The light source in this lamp should be replaced by the manufacturer or its service agent or a similarly qualified person


9. 10.





COB series installation instructions


SERIES	CUT-OUT	SERIES	CUT-OUT
DR00305	85×85 mm	DR00306	85×85 mm
DR00319	85×85 mm	DR00321	85×85 mm
DR00301	Ø85mm	DR00302	Ø85mm
DR00311	Ø85mm	DR00313	Ø85mm
DR00309	Ø85mm	DR00310	Ø85mm
DR00327	Ø85mm	DR00329	Ø85mm

INSTALLATION STEPS (Ø85mm)












Take out the front cover.


INSTALLATION STEPS (85x85mm)



main frames .







Connect the wire .

main frame.

