



Follo series installation instructions





Notice:


- 1 All operation must be in de-energized!
- 2 Ensure the handdle is in closed position before assemble the adapter to the track.
- 3 Put the handle to the point position after assemble the adapter to the track.
- 4 Keep the power off and ensure the handle is in closed position.
- 5 Shall use the track suitable for the lamp, and pay attention to the installation direction of the third-line track, that is,the one side of the light fixture has two copper plates should be fitted on the same side of the third-line track groove with two copper wires.














The specific appearance is subject to the real product!

4- wire connection instructions








.

2.

3


4



The specific appearance is subject to the real product!


6-wire wiring diagram:


5.




Optical Accessories Change:

Options: Linear lens, Honeycomb, Cross Louver







Do not clean LED chip and reflector with hand or towel!





- Use only drivers that comply with IEC or CE safety standards.
- Check if the power supply match with the luminaire.
- Must consider the maximum current value displayed on the label of the luminaire.
- The voltage displayed on the luminaire is not used to select the constant voltage driver, but the voltage covered by the selected constant current driver.
- Take suitable ESD measures to avoid touching bare conductors.
- LED chips can be damaged if be in touch with chemical material or gas. Therefore, it is not allowed to clean the LED housing or luminaire by chemicals.
- The following items are confirmed to have negative impact on the performance of the luminaire, avoid to keep luminaire in the same circumstance with them.

Methyl acetate or ethyl acetate (i.e., nail polish remover)

Cyanoacrylates (i.e., "Superglue")

Glycol ethers (including Radio Shack ® Precision Electronics

Cleaner - dipropylene glycol monomethyl ether)

Formaldehyde or butadiene (including Ashland PLIOBOND ® adhesive)

Dymax 984-LVUF conformal coating

Loctite Sumo Glue Loctite 384 adhesive Loctite 7387 activator

Gorilla Glue Bleach, Bleach-containing cleaners, sprays

- Remove the insulation material from the luminaire or provide enough space so that the temperature raising will not overpass the limited TC.
- LED chip is very sensitive to switching transients, therefore, LED lamps and appliances must be connected after power cut off, no hotswappable.
- Recommends using the driver indicated on the luminaire manual.
- Must consider the polarity of the product.
- -If the external flexible cable or cord of this lamp is damaged, the cord should be replaced by the manufacturer or its service agent or a similarly qualified person
- -The light source in this lamp should be replaced by the manufacturer or its service agent or a similarly qualified person

6.

8.